


ONE TOUCH FITTING / QUICK CONNECT FITTING

TUBE FITTING - P1									
PC		MODEL (? D-T)			POC		MODEL (? D-T)		
		Tube (Metric) -Thread (R)					Tube (Metric) -Thread (R)		
		PC 04-M5	PC 06-04	PC 12-01			POC 04-M5	POC 06-04	POC 12-01
		PC 04-M6	PC 08-01	PC 12-02			POC 04-M6	POC 08-01	POC 12-02
		PC 04-01	PC 08-02	PC 12-03			POC 04-01	POC 08-02	POC 12-03
		PC 04-02	PC 08-03	PC 12-04			POC 04-02	POC 08-03	POC 12-04
		PC 06-M5	PC 08-04	PC 16-03			POC 06-M5	POC 08-04	POC 16-03
		PC 06-M6	PC 10-01	PC 16-04			POC 06-M6	POC 10-01	POC 16-04
		PC 06-01	PC 10-02				POC 06-01	POC 10-02	
		PC 06-02	PC 10-03				POC 06-02	POC 10-03	
		PC 06-03	PC 10-04				POC 06-03	POC 10-04	
PCF		MODEL (? D-T)			PC-G		MODEL (? D-T)		
		Tube (Metric) -Thread (Rc)					Tube (Metric) -Thread (G)		
		PCF 04-M5	PCF 06-04	PCF 12-01			PC-G 04-M5	PC-G 06-04	PC-G 12-01
		PCF 04-M6	PCF 08-01	PCF 12-02			PC-G 04-M6	PC-G 08-01	PC-G 12-02
		PCF 04-01	PCF 08-02	PCF 12-03			PC-G 04-01	PC-G 08-02	PC-G 12-03
		PCF 04-02	PCF 08-03	PCF 12-04			PC-G 04-02	PC-G 08-03	PC-G 12-04
		PCF 06-M5	PCF 08-04	PCF 16-03			PC-G 06-M5	PC-G 08-04	PC-G 16-03
		PCF 06-M6	PCF 10-01	PCF 16-04			PC-G 06-M6	PC-G 10-01	PC-G 16-04
		PCF 06-01	PCF 10-02				PC-G 06-01	PC-G 10-02	
		PCF 06-02	PCF 10-03				PC-G 06-02	PC-G 10-03	
		PCF 06-03	PCF 10-04				PC-G 06-03	PC-G 10-04	
PMF		MODEL (? D-T)			PMM		MODEL (? D)		
		Tube (Metric) -Thread (Rc)					Tube (Metric)		
		PMF 04-M5	PMF 06-04	PMF 12-01			PMM 04		
		PMF 04-M6	PMF 08-01	PMF 12-02			PMM 06		
		PMF 04-01	PMF 08-02	PMF 12-03			PMM 08		
		PMF 04-02	PMF 08-03	PMF 12-04			PMM 10		
		PMF 06-M5	PMF 08-04	PMF 16-03			PMM 12		
		PMF 06-M6	PMF 10-01	PMF 16-04			PMM 16		
		PMF 06-01	PMF 10-02						
		PMF 06-02	PMF 10-03						
		PMF 06-03	PMF 10-04						
PI		MODEL (? D)			PSI		MODEL (? D1-? D2)		
		Tube (Metric)	Tube (Inch)				Tube (Metric)	Tube (Inch)	
		PI 04	PI 5/32				PSI 06-04	PSI 3/16-5/32	
		PI 06	PI 3/16				PSI 08-06	PSI 1/4-5/32	
		PI 08	PI 1/4				PSI 10-08	PSI 1/4-3/16	
		PI 10	PI 5/16				PSI 12-10	PSI 5/16-1/4	
		PI 12	PI 3/8					PSI 3/8-5/16	
			PI 1/2					PSI 1/2-3/8	
PUL		MODEL (? D)			PGL		MODEL (? D1-? D2)		
		Tube (Metric)	Tube (Inch)				Tube (Metric)		
		PUL 04	PUL 5/32				PGL 06-04		
		PUL 06	PUL 3/16				PGL 08-06		
		PUL 08	PUL 1/4				PGL 10-08		
		PUL 10	PUL 5/16				PGL 12-10		
		PUL 12	PUL 3/8				PGL 16-12		
		PUL 16	PUL 1/2						

TUBE FITTING - P2							
PUT 	MODEL (? D)			PGT 	MODEL (? D1-? D2)		
	Tube (Metric)				Tube (Metric)		
	PUT 04				PGT 06-04		
	PUT 06				PGT 08-06		
	PUT 08				PGT 10-08		
	PUT 10				PGT 12-10		
	PUT 12				PGT 16-12		
	PUT 16						
PUY 	MODEL (? D)			PGY 	MODEL (? D1-? D2)		
	Tube (Metric)				Tube (Metric)		
	PUY 04				PGY 06-04		
	PUY 06				PGY 08-06		
	PUY 08				PGY 10-08		
	PUY 10				PGY 12-10		
	PUY 12						
PLL 	MODEL (? D-T)			PL 	MODEL (? D-T)		
	Tube (Metric) -Thread (R)				Tube (Metric) -Thread (R)		
	PLL 04-M5	PLL 06-04	PLL 12-01		PL 04-M5	PL 06-04	PL 12-01
	PLL 04-M6	PLL 08-01	PLL 12-02		PL 04-M6	PL 08-01	PL 12-02
	PLL 04-01	PLL 08-02	PLL 12-03		PL 04-01	PL 08-02	PL 12-03
	PLL 04-02	PLL 08-03	PLL 12-04		PL 04-02	PL 08-03	PL 12-04
	PLL 06-M5	PLL 08-04	PLL 16-03		PL 06-M5	PL 08-04	PL 16-03
	PLL 06-M6	PLL 10-01	PLL 16-04		PL 06-M6	PL 10-01	PL 16-04
	PLL 06-01	PLL 10-02			PL 06-01	PL 10-02	
	PLL 06-02	PLL 10-03			PL 06-02	PL 10-03	
	PLL 06-03	PLL 10-04			PL 06-03	PL 10-04	
PLH 	MODEL (? D-T)			PLF 	MODEL (? D-T)		
	Tube (Metric) -Thread (R)				Tube (Metric) -Thread (Rc)		
	PLH 04-M5	PLH 06-04	PLH 12-01		PLF 04-M5	PLF 06-04	PLF 12-01
	PLH 04-M6	PLH 08-01	PLH 12-02		PLF 04-M6	PLF 08-01	PLF 12-02
	PLH 04-01	PLH 08-02	PLH 12-03		PLF 04-01	PLF 08-02	PLF 12-03
	PLH 04-02	PLH 08-03	PLH 12-04		PLF 04-02	PLF 08-03	PLF 12-04
	PLH 06-M5	PLH 08-04	PLH 16-03		PLF 06-M5	PLF 08-04	PLF 16-03
	PLH 06-M6	PLH 10-01	PLH 16-04		PLF 06-M6	PLF 10-01	PLF 16-04
	PLH 06-01	PLH 10-02			PLF 06-01	PLF 10-02	
	PLH 06-02	PLH 10-03			PLF 06-02	PLF 10-03	
	PLH 06-03	PLH 10-04			PLF 06-03	PLF 10-04	
PT 	MODEL (? D-T)			PST 	MODEL (? D-T)		
	Tube (Metric) -Thread (R)				Tube (Metric) -Thread (R)		
	PT 04-M5	PT 06-04	PT 12-01		PST 04-M5	PST 06-04	PST 12-01
	PT 04-M6	PT 08-01	PT 12-02		PST 04-M6	PST 08-01	PST 12-02
	PT 04-01	PT 08-02	PT 12-03		PST 04-01	PST 08-02	PST 12-03
	PT 04-02	PT 08-03	PT 12-04		PST 04-02	PST 08-03	PST 12-04
	PT 06-M5	PT 08-04	PT 16-03		PST 06-M5	PST 08-04	PST 16-03
	PT 06-M6	PT 10-01	PT 16-04		PST 06-M6	PST 10-01	PST 16-04
	PT 06-01	PT 10-02			PST 06-01	PST 10-02	
	PT 06-02	PT 10-03			PST 06-02	PST 10-03	
	PT 06-03	PT 10-04			PST 06-03	PST 10-04	

TUBE FITTING - P3						
PWY	MODEL (? D-T)			PULL	MODEL (? D-T)	
	Tube (Metric) -Thread (R)				Tube (Metric) -Thread (R)	
	PWY 04-M5	PWY 06-04	PWY 12-01		PULL 06-01	
	PWY 04-M6	PWY 08-01	PWY 12-02		PULL 06-02	
	PWY 04-01	PWY 08-02	PWY 12-03		PULL 06-03	
	PWY 04-02	PWY 08-03	PWY 12-04		PULL 06-04	
	PWY 06-M5	PWY 08-04	PWY 16-03		PULL 08-01	
	PWY 06-M6	PWY 10-01			PULL 08-02	
	PWY 06-01	PWY 10-02			PULL 08-03	
	PWY 06-02	PWY 10-03			PULL 08-04	
	PWY 06-03	PWY 10-04				
PLM	MODEL (? D1-? D2)			PHZ	MODEL (? D1-? D2)	
	Tube (Metric)				Tube (Metric)	
	PLM 04-12X1				PHZ 04-06	
	PLM 06-14X1				PHZ 06-08	
	PLM 08-16X1				PHZ 08-10	
	PLM 10-18X1				PHZ 10-12	
	PLM 12-20X1					
PZR	MODEL (? D-T)			PZA	MODEL (? D)	
	Tube (Metric) -Thread (R)				Tube (Metric)	Tube (Inch)
	PZR 04-M5	PZR 06-04		PZA 04	PZA 5/32	
	PZR 04-M6	PZR 08-01		PZA 06	PZA 3/16	
	PZR 04-01	PZR 08-02		PZA 08	PZA 1/4	
	PZR 04-02	PZR 08-03		PZA 10	PZA 5/16	
	PZR 06-M5	PZR 08-04		PZA 12	PZA 3/8	
	PZR 06-M6	PZR 10-01			PZA 1/2	
	PZR 06-01	PZR 10-02				
	PZR 06-02	PZR 10-03				
	PZR 06-03	PZR 10-04				
PKS	MODEL (? D1-? D2)			FD	MODEL (? D1-? D2)	
	Tube (Metric)				Tube (Metric)	
	PKS 04				FD 04	
	PKS 06				FD 06	
	PKS 08				FD 08	
	PKS 10				FD 10	
	PKS 12				FD 12	
PK	MODEL (? D)			PKG	MODEL (? D1-? D2)	
	Tube (Metric)				Tube (Metric)	Tube (Inch)
	PK 06				PKG 06-04	PKG 3/16-5/32
	PK 08				PKG 08-04	PKG 1/4-5/32
	PK 10				PKG 08-06	PKG 5/16-5/32
	PK 12				PKG 10-08	PKG 5/16-3/16
					PKG 12-10	PKG 5/16-1/4
						PKG 3/8-1/4
					PKG 3/8-5/16	

TUBE FITTING - P4							
PKD	MODEL (? D1-? D2)		PKJ	MODEL (? D1-? D2)			
	Tube (Metric)			Tube (Metric)	Tube (Inch)		
	PKD 06-01	PKD 10-02		PKJ 06-04	PKJ 3/16-5/32		
	PKD 06-02	PKD 10-03		PKJ 08-04	PKJ 1/4-5/32		
	PKD 06-03	PKD 10-04		PKJ 08-06	PKJ 5/16-5/32		
	PKD 06-04	PKD 12-01		PKJ 10-06	PKJ 5/16-3/16		
	PKD 08-01	PKD 12-02		PKJ 10-08	PKJ 5/16-1/4		
	PKD 08-02	PKD 12-03			PKJ 3/8-1/4		
	PKD 08-03	PKD 12-04			PKJ 3/8-5/16		
	PKD 08-04						
	PKD 10-01						
PLJ	MODEL (? D)		JSS	MODEL (? D-T)			
	Tube (Metric)	Tube (Inch)		Tube (Metric) -Thread (R)			
	PLJ 04	PLJ 5/32		JSS 04-M5	JSS 06-04	JSS 12-03	
	PLJ 06	PLJ 3/16		JSS 04-M6	JSS 08-01	JSS 12-04	
	PLJ 08	PLJ 1/4		JSS 04-01	JSS 08-02		
	PLJ 10	PLJ 5/16		JSS 04-02	JSS 10-01		
	PLJ 12	PLJ 3/8		JSS 06-M5	JSS 10-02		
		PLJ 1/2		JSS 06-M6	JSS 10-03		
				JSS 06-01	JSS 10-04		
				JSS 06-02	JSS 12-01		
				JSS 06-03	JSS 12-02		
PHF	MODEL (? D-T)			PH	MODEL (? D-T)		
	Tube (Metric) -Thread (R)				Tube (Metric) -Thread (R)		
	PHF 04-M5	PHF 06-04	PHF 12-01		PH 04-M5	PH 06-04	PH 12-01
	PHF 04-M6	PHF 08-01	PHF 12-02		PH 04-M6	PH 08-01	PH 12-02
	PHF 04-01	PHF 08-02	PHF 12-03		PH 04-01	PH 08-02	PH 12-03
	PHF 04-02	PHF 08-03	PHF 12-04		PH 04-02	PH 08-03	PH 12-04
	PHF 06-M5	PHF 08-04			PH 06-M5	PH 08-04	
	PHF 06-M6	PHF 10-01			PH 06-M6	PH 10-01	
	PHF 06-01	PHF 10-02			PH 06-01	PH 10-02	
	PHF 06-02	PHF 10-03			PH 06-02	PH 10-03	
	PHF 06-03	PHF 10-04			PH 06-03	PH 10-04	
PHW	MODEL (? D-T)			PUA	MODEL (? D)		
	Tube (Metric) -Thread (R)				Tube (Metric)		
	PHW 06-01	PHW 12-03			PUA 04		
	PHW 06-02				PUA 06		
	PHW 08-01				PUA 08		
	PHW 08-02				PUA 10		
	PHW 08-03						
	PHW 10-01						
	PHW 10-02						
	PHW 10-03						
	PHW 12-02						
PA	MODEL (? D)			PUI	MODEL (? D-T)		
	Tube (Metric)				Tube (Metric)	Tube (Metric) -Thread (R)	
	PA 06				PUI 04-M5	PUI 08-02	
	PA 08				PUI 04-01	PUI 08-03	
	PA 10				PUI 04-02	PUI 08-04	
	PA 12				PUI 06-M5	PUI 10-02	
					PUI 06-01	PUI 10-03	
					PUI 06-02	PUI 10-04	
					PUI 06-03	PUI 12-02	
					PUI 06-04	PUI 12-03	
					PUI 08-01	PUI 12-04	

TUBE FITTING - P5					
HVFS	MODEL (? D-T)		HVFF	MODEL (? D1-? D2)	
	Tube (Metric) -Thread (R)			Tube (Metric)-Tube (Metric)	
 $\Phi D(IN)$ $T(OUT)$	HVFS 06-01	HVFS 12-02	 $\Phi D1(IN)$ $\Phi D2(OUT)$	HVFF 06-06	
	HVFS 06-02	HVFS 12-03		HVFF 08-08	
	HVFS 06-03	HVFS 12-04		HVFF 10-08	
	HVFS 08-01			HVFF 10-10	
	HVFS 08-02				
	HVFS 08-03				
	HVFS 10-02				
	HVFS 10-03				
	HVFS 10-04				
HVSS	MODEL (T-T)		PYJ	MODEL (? D)	
	Thread (R) -Thread (R)			Tube (Metric)	Tube (Inch)
	HVSS 01-01		 ΦD	PYJ 04	PYJ 5/32
	HVSS 02-02			PYJ 06	PYJ 3/16
	HVSS 03-03			PYJ 08	PYJ 1/4
	HVSS 03-02			PYJ 10	PYJ 5/16
	HVSS 04-03			PYJ 12	PYJ 3/8
	HVSS 04-04				PYJ 1/2
PGJ	MODEL (? D1-? D2)		PP	MODEL (? D)	
	Tube (Metric)-Tube (Metric)			Tube (Metric)	
 $\Phi D1$ $\Phi D2$	PGJ 06-04			PP 04	
	PGJ 08-04			PP 06	
	PGJ 10-06			PP 08	
	PGJ 10-08			PP 10	
	PGJ 12-08			PP 12	
	PGJ 12-10				
PIJ	MODEL (? D)		PIG	MODEL (? D1-? D2)	
	Tube (Metric)	Tube (Inch)		Tube (Metric)	Tube (Inch)
 ΦD	PIJ 04	PIJ 5/32	 $\Phi D2$ $\Phi D1$	PIG 06-04	PIG 3/16-5/32
	PIJ 06	PIJ 3/16		PIG 08-06	PIG 1/4-5/32
	PIJ 08	PIJ 1/4		PIG 10-08	PIG 1/4-3/16
	PIJ 10	PIJ 5/16		PIG 12-10	PIG 5/16-1/4
	PIJ 12	PIJ 3/8			PIG 3/8-5/16
		PIJ 1/2			PIG 1/2-3/8